


**Thank you** for your purchase!

Instructions made easy



Read instructions or watch easy-to-follow video.

**Scan code or visit**  
<https://byjasco.com/59325i>

*Exclusive deals*



For deals, to register your purchase and to tell us how we're doing, simply scan the code or visit [byjasco.com/deals](https://byjasco.com/deals)



Discover more lighting from Energizer at [byjasco.com](https://byjasco.com)



**Like our product?**  
Leave a review on your favorite retailer website or [amazon.com](https://amazon.com)

**Having problems?**  
Let us know how we can help.  
**1-800-654-8483**  
between 7AM-8PM,  
M-F, Central Time.



***Energizer***<sup>®</sup>



**Motion-Sensing  
LED Puck Lights**



## LED Puck

### BATTERY INSTALLATION:

1. Open the back-facing battery cover to reveal the battery compartment.
2. Insert 3 AAA batteries, noting polarity. Replace the cover and make sure it clicks firmly into place.

### MOUNTING INSTRUCTIONS:

1. Use the included screws with the keyholes or hook-and-loop tape. Make sure the area is clean and dry before mounting.
2. To install the puck using screws, use the included mounting template to mark each screw location. Install the screws and mount the puck.

### OPERATION


Use the ON/OFF/AUTO switch inside the battery compartment to set light to your preferred setting.

**ON:** The light will be set to always on

**OFF:** The light will be off and save battery life

**AUTO:** The light will turn on when motion is detected up to 15ft. away while in low light conditions

*Note: There is a 30-second timeout feature that will turn the light OFF after no motion is detected to conserve battery life.*




MADE IN CHINA

©2021 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Jasco Products Company, LLC.

Contact our U.S.-based Consumer Care at 1-800-654-8483 between 7AM-8PM, M-F, Central Time.

90-day warranty. Visit [www.byjasco.com](http://www.byjasco.com) for warranty details.



## Disco LED

### COLOCACIÓN DE LAS PILAS:

1. Abra la tapa del compartimento para pilas en la parte posterior para acceder al compartimento
2. Inserte 3 pilas AAA, teniendo en cuenta los polos. Vuelva a colocar la tapa y asegúrese de que encaje firmemente en su lugar.

### INSTRUCCIONES DE MONTAJE:

1. Utilice los tornillos incluidos con los orificios o la cinta de gancho y bucle. Asegúrese de que el área esté limpia y seca antes de realizar el montaje.
2. Para instalar el disco con los tornillos, utilice la plantilla de montaje incluida para marcar la ubicación de cada tornillo. Inserte los tornillos y monte el disco.

### FUNCIONAMIENTO:

Utilice el interruptor de ON/OFF/AUTO (encendido/apagado/automático) dentro del compartimiento de las pilas para configurar la luz en su ajuste preferido.

**ON:** La luz se configura para estar siempre encendida.

**OFF:** La luz se apagará y ahorrará batería.

**AUTO:** La luz se encenderá cuando se detecte movimiento hasta 4,6 m (15 ft) habiendo condiciones de poca luz.

*Note: Hay una función de tiempo de espera de 30 segundos que apagará la luz después de no detectar movimiento para preservar la vida útil de las pilas.*

HECHO EN CHINA

©2021 Energizer. Energizer y algunos diseños gráficos son marcas comerciales de Energizer Brands, LLC y subsidiarias relacionadas, que se utilizan bajo la licencia de Jasco Products Company, LLC. Todos los demás nombres de marca que aparecen son marcas comerciales pertenecientes a sus respectivos propietarios. Ni Jasco Products Company, LLC ni Energizer Brands, LLC están relacionados con los propietarios respectivos de sus marcas comerciales

¿Preguntas? Comuníquese al 1-800-654-8483 entre las 7:00 a.m. y las 8:00 p.m. CST (hora central estándar)

Garantía de 90 días. Visite [www.byjasco.com](http://www.byjasco.com) para conocer los detalles de la garantía.

